


Clay Paky Stage Color 300

Stage-Color_300



256

Switch function: 4=on
Pan (rot.) [5] - Tilt (basc.) [6]
Pan fine [9] - Tilt fine [10]

Dimmer [7]

Frost

Strobe [4]

rapide

lent

Clay Paky

Stage Color HTI 300

Faisceau étroit

Couleur R[1] V[2] B[3]

